

Laser Spectroscopy of HeH⁺

施 宙聰

2011 AMO TALK

2011/9/26


Outline

- Introduction
- Previous experimental results
- Saturation spectroscopy
- Conclusions and future works

Diatom Molecules

- Total energy=electronic energy + vibrational energy + rotational energy

$$E_{tot} = E_{elec} + E_{vib} + E_{rot}$$



$E_{elec} \sim \text{few eV}$

$E_{vib} \sim E_{elec}/100$

$E_{rot} \sim E_{vib}/100$

Rovibronic transition Vis, UV

Rotation-vibrational IR

Rotational μwave, THz


Simple Diatomic Molecules

- One-electron: H_2^+ , HD^+ , D_2^+
 - Two-electron: H_2 , HD , D_2 , HeH^+
- HD^+ , HeH^+ : electric dipole moment
for rotation-vibration transitions

Why HeH⁺?

- One of the simplest two-electron diatomic molecules: benchmark of theoretical calculation
- It is formed by hydrogen and helium, the two most abundant elements in the universe. It is the first molecule in the universe.
- HeH⁺ had been suggested presenting in the astronomical objects such as nebula, supernova, white dwarfs and quasi-stellar object (QSO)envelop.

Potential curves of HeH⁺



Theoretical calculations


- Born-Oppenheimer (BO) approximation
- Non-adiabatic calculation
- Relativistic corrections
- QED corrections

Generation and destruction of HeH⁺

- Generation




- Destruction



Spectroscopic methods

- Doppler-tuned ion beam spectroscopy
- Laser absorption spectroscopy in discharge

Spectroscopy Using Ion Beam



Willis Lamb (1913 -2008)
1955 Nobel prize
Mossbauer effect
Lamb shift
Laser physics
Lamb dip




William H. Wing
University of Arizona

Doppler tuning: tuning range depends on laser frequency, ion mass and accelerating voltage

High resolution: velocity compression
Linewidth ~ 10 MHz

Collision detection: low signal-to-noise ratio



Spectroscopy Using Discharge



Gerhard Herzberg (1904-1999)
1971 Nobel prize in chemistry



Takashi Oka
First observation of H_3^+ IR spectrum


Observation of H_3^+ IR spectrum by Oka (1980)

- Tunable DFG source
- LN2 cooled hydrogen discharge
- Absorption spectrum with 32 m length

Observation of HeH^+ fundamental band spectrum by Bernath and Amano (1982)

4% absorption for R(1) transition in fundamental band

Velocity Modulation Spectroscopy




Sensitive to ions not to neutrals



Richard Saykally (UC Berkeley) 1983


Velocity Modulation Spectroscopy

- ▶ Positive column discharge cell
 - High ion density, rich chemistry
 - Cations move toward the cathode
 - Ions absorption profile is Doppler-shifted




Velocity Modulation Spectroscopy

- ▶ Positive column discharge cell
 - High ion density, rich chemistry
 - Cations move toward the cathode
 - Ions absorption profile is Doppler-shifted



Velocity Modulation Spectroscopy

- ▶ **Positive column discharge cell**
 - High ion density, rich chemistry
 - Cations move toward the cathode
 - Ions absorption profile is Doppler-shifted
- ▶ **Drive with AC voltage**
 - Ion Doppler profile alternates red/blue shift
 - Laser at fixed wavelength
 - Demodulate detector signal at modulation frequency



Taken from Prof. B.J. McCall's talk

Laser Spectroscopy of ${}^4\text{HeH}^+$

Authors	Method	Measured Transitions	Accuracy (MHz)
[1979] D.E. Tolliver, G. A. Kyrala and W.H. Wing	Ion beam	Fundamental Band : P(12)-P(13) $v = 2-1$: P(9)-P(11)	60
[1982] P. Bernath and T. Amano	Absorption	Fundamental Band : R(0)-R(4) and P(1)-P(4)	30~60
[1989] M.W. Crofton, R.S. Altman, N.N. Haese and T. Oka	VM	$v=1-2$ R(1)-R(5), R(8), P(1) and its isotopes	60
[1997] F. Matsushima, T. Oka and K. Takagi	VM	Low J pure rotation R(0) and R(1)	0.2
[1997] Z. Liu and P.B. Davies	VM	Quasi-bound to quasi-bond and bond to quasi-bond	90

HeH^+ Pure Rotation Transitions

- Tunable FIR source:
two CO_2 lasers + microwave + MIM diode
frequency up to 6 THz
 μW power
LHe cooled bolometer

Oka and Takaji 1997

The lowest $J = 1 \rightarrow 0$ transition of ${}^4\text{HeH}^+$ observed at 2010.1839(2) GHz will be an important future probe for detecting this species in space.

Saturation Spectroscopy of Molecular Ions (H_3^+ and HeH^+)

How to achieve?

- > Light Source – CW Optical Parametric Oscillator

---- Enough power for saturation.


- > Extended Negative Glow Discharge Tube

---- Low pressure, high concentration of ion.

- > Optical Frequency Comb

---- Frequency ruler for precision measurement.


PPLN (periodically poled LiNbO₃)




Quasi-phase matching
High nonlinear efficiency
over 0.4 to 5 μm

$$k_1 \rightarrow k_2 \rightarrow K_g \rightarrow k_3 = k_1 + k_2 + K_g$$

$$K_g = \frac{2\pi}{\Lambda}$$





Singly Resonant PPLN OPO



- Unlike other MIR light source, OPO provides larger power which is benefit for the saturation spectroscopy of molecular ion.
- Idler Wavelength: **2.7 – 3.9 μm**
- Average Power: **> 300 mW**
- Frequency Tuning: **> 40 GHz (Mode-Hop-Free)**
- Free-Running Stability: **< 500 MHz @ 8 hours**
- Pump: **1062 nm alpha-DFB laser boosted to 6 W by a YDFA**


Glow Discharge



Features of negative glow region:


- ▶ Largest glow intensity
- ▶ Highest concentration of positive ions
- ▶ Nearly field free
- ▶ **The region is relatively short**

Extended Negative Glow Discharge




Benefits of extended negative glow :

- Lower gas pressure (~100 mtorr)
- Narrower linewidth for precision measurement
- Flow mixture of He:H₂ = 98 : 2 (120 mtorr)
- Discharge Current : 16 mA
- Ethanol cooled at -70 °C
- Discharge length = 150 cm



Experimental Setup for saturation spectroscopy




Pump Power: ~110 mW

Beam Size: 1.75 mm (Diameter, $1/e^2$)


Probe beam ~ 10 mW

The intensity is ~ 40 kW/m²

Doppler Broadened Spectrum



3rd Derivative Spectrum




Frequency Modulation Method (by modulating the pump frequency)

Modulation Frequency : 31 kHz

Modulation Depth : 7.6 MHz

Laser Intensity : $\sim 40 \text{ kW/m}^2$ (or 40 mW/mm^2)

Linewidth analysis



ITRI Fiber OFC


- Repetition Rate : 250 MHz
- Supercontinuum : 1030 ~ 2200 nm
- RF Reference : GPS-locked Rubidium clock
- Accuracy : < 10^{-11} @ 1000 sec (~few kHz in the MIR region)

1.062 μm 1.4-1.8 μm 2.7-3.9 μm


$$\omega_{pump} = \omega_{signal} + \omega_{idler}$$



Frequency measurement



Frequency measurement results



Frequency Measurement: $90788\,392.057 \pm 0.076$ MHz

Conclusions and Future Works

- First observation of saturation spectrum of HeH^+
- Absolute frequency measurement better than 100 kHz (~ 1 ppb accuracy)

In future

- Saturation spectroscopy of H_3^+ , HeD^+
- Velocity modulation spectrum of HeH^+ and HeD^+ using PPLN DFG (breakdown of BO approximation)

Acknowledgements




- We thank to the National Science Council (NSC), Ministry of Education, Natural Science and Engineering Research Council of Canada (NSERC) and Industrial Technology Research Institute.

Thanks For your Attention!



Frequency Comb




Ti:Saphire Kerr-lens
mode locked laser

$\omega_r = 1/T$, T : repetition time
Controlled by cavity length

$\Delta\varphi$ pulse-to-pulse carrier
envelope phase shift
Controlled by pulsed power

$$\omega_n = n\omega_r + \omega_{CE}$$

f - $2f$ self-reference



$\Delta\nu/\nu = 1 \times 10^{-15}$ 上限 $\Delta\nu/\nu = 1 \times 10^{-18}$