



National Chiao Tung University
College of Photonics

Aligning liquid crystal molecules by nanoparticles

鄭協昌

交通大學光電學院
影像與生醫光電研究所

2012/04/16



國立交通大學
National Chiao Tung University
台南校區
光電學院

Outlines


- Motivation
- Liquid Crystal Alignment
- Nanoparticle-induced vertical alignment for pretilt control
- Pretilt angle controlled by UV treatment
- Applications
- Conclusion



國立交通大學
National Chiao Tung University
台南校區
光電學院

2

Motivation – Flexible Displays



世界最大の
電子ペーパーサイネージ
技術C線!

– How fast to double a knowledge base*?

- 1750 – 1900: 150 years to double
- 1900 – 1950: 50 years to double
- 1950 – 1960: 10 years to double
- 1960 – 1992: 5 years to double

By 2020, information might double about every **73** days!

國立
中央
大學
光電學院

3

台灣LCD面板產業切入點 – 軟性高階 TFT-LCD


適合台灣面板產業切入

Display Devices

Display Options: UTL™ (Ultra-thin and Light-weight) Flexible Display

	E-Paper Display (Electrophoretic)	Active matrix LCD	Active matrix OLED
			
😊	- Ink-on-paper look (B/W) - Production on glass available - Low power consumption - Flexibility	- Full color - High resolution - Can use conventional LCD line	- High flexibility - Full color - Low cost printing process – polymer
😞	- Active matrix driving - Color → CF for colored particles - Slow response time	- Cell gap control - Back light unit - Alignment layer - Handling	- Thin film encapsulation - Handling

軟性TFT背板製程評估



國立交通大學
National Tsing Tung University
台南校區
光電學院


關鍵材料及技術：塑膠與玻璃貼合及剝離

5

Challenges

High temperature process: TFT, CF, PI baking

	Total Transmittance (%)	Haze (%)	Retardation (%)	CTE (ppm/°C)	Heat shrinkage (%)
Glass	93	93	1	3.7	0
PC	90	90	1	73	0.01 @ 180°C 2hr




Two approaches:

- Lower process temperature
- Increase plastics Tg/ Reduce CTE

國立交通大學
National Tsing Tung University
台南校區
光電學院

6

LCD Structure



Approaches for flexible LCDs

Noval structures

- No alignment layer
- No color filter – fast response

Non-alignment

Isotropic to anisotropic

US 20050062927A1

(19) **United States**

(12) **Patent Application Publication** (10) Pub. No.: **US 2005/0062927 A1**

Nakamura et al.

(43) Pub. Date: **Mar. 24, 2005**

(54) **LIQUID CRYSTAL DISPLAY DEVICE**


Publication Classification

(75) Inventors: Masako Nakamura, Nara (JP); Yoshito Hashimoto, Mie (JP); Tokihiko Shinomiya, Nara (JP); Shigeaki Mizushima, Nara (JP)

(51) Int. Cl.⁷ G02F 1/133

(52) U.S. Cl. 349/170; 349/167


Sharp's concept




9

VA-mode without PI alignment layers


LC+ POSS




0 V



3 V



Sigma-Aldrich Corp.



多面體矽氧烷寡聚物(polyhedral oligomeric silsesquioxane, POSS)

10

Application I: Flexible Guest-Host LCDs

Incident light

V off

(c)

Incident light

V on

(d)

OFF

ON

Black Yellow
Red Blue

Fig. 3 Different color PDMLC device at 1 inch.

PET substrate
Ball spacer

國立交通大學
National Tsing Hua University
光電學院

Vol. 33, No. 15 / OPTICS LETTERS 1663

11

Flexible Homeotropic PET-LCDs

國立交通大學
National Tsing Hua University
光電學院

12

Voltage-dependent Transmission Pretilt-control ?




Figure 4. Measured voltage-dependent optical transmission curves of homeotropic LC cells doped with different wt% POSS.





Figure 5. A series of simulated voltage-dependent optical transmission curves with different pretilt angles.

Outlines

- Pretilt for LCDs and their applications
- Nanoparticle-induced vertical alignment for pretilt control
- Pretilt angle controlled by UV treatment
- Applications
- Conclusion


LCD Structure



Pretilt determines all E-O properties:
driving voltage, viewing angle, response time, color

Required pretilt depends on operation modes

In-Plane Switching




Alignment layers vs. Products

- ~1°: In-Plane Switching (IPS)
- ~4°: Twist Nematic (TN)
- ~7°: Super Twist Nematic
- ~50°: Bistable bend-splay
- ~50°: No-bias OCB
- ~90°: Vertically aligned (VA)



Twist-Nematic (TN) LCDs




Alignment layers vs. Products


~1°: In-Plane Switching (IPS)
 ~4°: Twist Nematic (TN)
 ~7°: Super Twist Nematic
 ~50°: Bistable bend-splay
 ~50°: No-bias OCB
 ~90°: Vertically aligned (VA)



Homeotropic (Vertical) Alignment



$V=0$



$V>V_{th}$

~1°: In-Plane Switching (IPS)
 ~4°: Twist Nematic (TN)
 ~7°: Super Twist Nematic
 ~50°: Bistable bend-splay
 ~50°: No-bias OCB
 ~90°: Vertically aligned (VA)



LCD-TV


Alignment layers

Commercial homogeneous polyimide
low pretilt < 10°

Commercial homeotropic polyimide
high pretilt ~ 90°

~1°: In-Plane Switching (IPS)
~4°: Twist Nematic (TN)
~7°: Super Twist Nematic
~50°: Bistable bend-splay
~50°: **No-bias optically-compensated bend (OCB)**
~90°: Vertically aligned (VA)

OCB LC cell



OCB:

Fast response time
Wide viewing angle



21

Applications of OCB-LCDs

Examples:

Power-saving

- **No color filter-** color sequential (field sequential) with RGB backlights
Color filters Waste ~70% of incident light

Naked-eyes 3D- Displays

- **Fast active barrier (120 Hz):**
 - ✓ full resolution by time-multiplexed and spatial-multiplexed
 - ✓ 2D/3D switchable




22

Optically-Compensated-Bend mode (OCB)

Fast response and wide-viewing angle

OCB is normally operated at bend state




Elastic Deformation Energy of OCB LCDs

$$E = \frac{1}{2} \int_0^d (K_{11} \cos^2 \theta + K_{33} \sin^2 \theta) \left(\frac{d\theta}{dz} \right)^2 dz,$$

K_{11} and K_{33} are the splay and bend elastic constants.

θ is the tilt angle which is a function of distance



Approaches of tunable pretilt angles

➤ SiOx oblique evaporation

➤ Polymer-stabilized alignment

➤ Nanostructured surfaces


➤ Hybrid mixture of two materials

➤ Chemical synthesis


➤ Stacked alignment layers

➤ Nanoparticle


➤ UV treatment



T. J. Chen
Appl. Phys. Lett. 92(9), 091102 (2008).



L. Komitov,
J. Soc. Inf. Disp. 16(9), 919 (2008).




H. S. Kwok
Appl. Phys. Lett. 88(5), 051910 (2006).



25

Mechanism of controlling pretilt angles

Friedel-Creagh-Kmetz (FCK) Rule



Contact angle measurement

Homeotropic PIs: low surface energy
Homogeneous PIs: high surface energy

$\gamma_s < \gamma_{lc} \rightarrow$ Homeotropic alignment

$\gamma_s > \gamma_{lc} \rightarrow$ Homogeneous alignment

γ_s : surface energy of a solid film

γ_{lc} : surface energy of LC

➤ Nanoparticle

➤ UV irradiation



Surface treatment




26

Outlines

- LCD alignment and applications
- Nanoparticle-induced vertical alignment for pretilt control
- Pretilt angle controlled by UV treatment
- Applications
- Conclusion



Approaches for Pretilt Control

1. POSS doped in planar LC cells
2. POSS doped in homogeneous PIs



polyhedral oligomeric silsesquioxane (POSS)

- Vertical alignment property
- Surface energy modification by POSS





(a) 0V


(b) 3.0V

Approach to control pretilt angle

I: LC doped with POSS




Polarizing microscope photographs of an LC cell doped with various POSS concentrations:



Opt. Lett. 34(4), 455-457 (2009).

29

Approach II: Homogeneous Polyimide doped with POSS




Pretilt angle and surface energy of POSS/PI alignment layers as a function of POSS concentration in PI.



OPTICS EXPRESS, 18, 16508 (2010)


30

Transitions of OCB LC cells



Voltage dependent transmission curves of OCB LCDs

- Traditional OCB LCD: low pretilt
- Proposed OCB LCD: high pretilt




Response time of a no-bias OCB LCD

The typical values:

Cell gap: $\sim 4.5 \mu\text{m}$

Pretilt angle: $\sim 65^\circ$

Driving: 0 V– 5 V



Total response time: $\sim 2.3 \text{ ms}$

Outlines

- LCD alignment and applications
- Nanoparticle-induced vertical alignment for pretilt control
- Pretilt angle controlled by UV treatment
- Applications
- Conclusion

Influence of UV on alignment layers

Photo-decomposition

UV-induced surface modification on homogeneous PI layers

FTIR spectra: bond-breaking reactions for homogeneous PI

5028 J Appl Phys **80** (9), 1 November 1996

We focus on:


UV-treatment on homeotropic PI layers

Pretilt tuning range: 90° to 0°

LC devices requiring patterned alignment areas.

Influence of UV dosage on PI films

pretilt angle and surface energy



UV intensity: 37 mW/cm²

Applications of UV treatment on PI films


Any LC device requires patterned alignment

Applications I: Liquid Crystal Fresnel Lens


Applications II: Liquid Crystal Phase Grating

Applications I: Liquid Crystal Fresnel Lens


Fabrication process



Focus of Liquid Crystal Fresnel Lens




A polarization-independent LC Fresnel lens




Applications II: Liquid Crystal Phase Grating

Fabrication process




Cell gap: $5.5 \mu\text{m}$
LC: E7



Photos by a crossed polarizing optical microscope.

First-order diffraction efficient



Conclusion and Future work

- POSS nanoparticle and UV irradiation have been applied for controlling pretilt angle of PI films.
- LC devices by these two techniques were demonstrated:
no-bias OCB LCDs, Fresnel lens, phase grating
- Determine the physical and chemical properties of PI/POSS and UV-treated PI alignment films in the near future.
- Reliability test in the near future:
thermal aging, voltage holding ratio, etc.


教學研究空間

奇美樓總樓地面積6,000坪
第一期校地面積8.2公頃

核定招生名額

	光電系統 研究所	照明與能 源研究所	影像與生 醫研究所	碩士 在職專班	合計
碩士生	30	30	30	30	120
博士生	10	10	3	0	23

THANKS FOR YOUR ATTENTION



College of Photonics
National Chiao Tung University at Tainan, Taiwan



國立交通大學
National Chiao Tung University
光電學院